



Посібник користувача - Energoefektivitets / Vadovas - Energijos vartojimo efektyvumo / Manwal ghall-Utent - Effiċjenza fl-Energija / Kézi - Energiahatékonyág / Příručka - Energetická účinnost

Priručka - Energetická účinnost / Manual - Eficientă Energetică / Ręczny - Efektywność energetyczna / Priručnik - Energetska efikasnost / Navodilo - Energetska učinkovitost

Εγχειρίδιο - Ενεργειακή Απόδοτικότητα / Manuel - Energi Verimliliği / Наръчник - Энергийна ефективност / Упутство - Енергетска ефикасност / Lámhleabhar Úsáideoir - Éifeachtúlacht Fuinnimh

Table with 17 columns (S, M, AEchood, EEC, FDEhood, FDEC, LEhood, LEC, GFEhood, GFEC, Qmin, Qmax, Qboost, SPEmin, SPEmax, SPEboost, PO, Ps, F, EEIhood, Qbep, Pbeep, Qmax, Wbep, WL, Emiddle, Lwa, PF, S, M, AEC, EEC, FDE, FDEC, LE, LEC, GFE, GFEC, Qmin, Qmax, Qboost, SPEmin, SPEmax, SPEboost, PO, Ps, F, EEIhood, Qbep, Pbeep, Qmax, Wbep, WL, Emiddle, Lwa, UA, LT, MT, CZ, SK, RO, PL, HR, SL, GR, TR, BG, SR, TA) and rows detailing technical specifications for the FABER P2550 hood. It includes sections for general information, technical data, safety, and maintenance in multiple languages.